

# Measuring Acoustic Parameters of a Room using REW Software

Dr. Janaka V. Wijayakulasooriya  
Department of Electrical and Electronic Engineering

## 1. Introduction

Room acoustics critically influence sound quality in studios, auditoriums, classrooms, and performance spaces. **Room EQ Wizard (REW)** is a free, powerful software widely used for:

- Measuring **Reverberation Time (RT60)**
- Measuring **Sound Pressure Levels (dB SPL)** at different locations
- Measuring **Frequency Response** of the room

This note guides practical measurement techniques, equipment requirements, and interpretation of results.

## 2. Required Equipment

1. **Laptop / PC** with REW installed (<https://www.roomeqwizard.com/>)
2. **Measurement Microphone**, preferably:
  - Calibrated USB mic (e.g., MiniDSP UMIK-1)
  - XLR condenser measurement mic with phantom power + audio interface
3. **Tripod** for mic placement at ear level
4. **Speaker or audio source** with flat frequency response
5. **Audio Interface** (if using XLR mic)
6. **Calibration files** for mic (if available)

## 3. Measuring RT60 (Reverberation Time)

### 3.1 What is RT60?

RT60 is the **time taken for sound to decay by 60 dB** after the source stops. It indicates room reverberance.

### 3.2 Steps for RT60 Measurement

1. Set up the mic at desired location(s).
2. Connect mic to REW and load calibration file if available.
3. In REW, select “**Impulse Response**” measurement.
4. Generate a **sweep signal** via speaker.
5. REW records the room’s response and calculates RT60 using the **Schroeder integration method**.
6. Analyze RT60 across frequency bands (125 Hz – 4 kHz).

### 3.3 Interpretation

- **Studios:** 0.2 – 0.4 s
- **Classrooms:** 0.6 – 0.8 s
- **Auditoriums:** 1.2 – 1.8 s

Long RT60 → echoey; short RT60 → dry sound.

## 4. Measuring Sound Pressure Level (dB SPL)

### 4.1 Purpose

Assessing **sound distribution uniformity** to detect level variations in the room.

### 4.2 Procedure

1. In REW, open **SPL Meter**.
2. Calibrate SPL reading using a reference SPL meter if available.
3. Emit pink noise at known level.
4. Measure dB SPL at multiple locations and record results.

### 4.3 Application

Ensures even coverage in PA system design and identifies dead spots or excessively loud areas.

## 5. Measuring Frequency Response

### 5.1 Purpose

Assessing how different frequencies are reproduced in the room to identify:

- Room modes
- Standing wave issues
- Excessive absorption at specific frequencies

### 5.2 Procedure

1. In REW, choose “**Measure**” and set sweep range (20 Hz – 20 kHz).
2. Perform sweep; REW records frequency response curve.
3. Analyze peaks (room modes) and dips (phase cancellations or absorptive losses).
4. Apply smoothing (1/6 octave) for interpretation.

### 5.3 Application

- Planning acoustic treatment (bass traps, absorbers, diffusers).
- Optimizing speaker placement and listener position.

## 6. Best Practices

- Use **calibrated equipment**.
- Measure at **multiple mic locations** for averaging.
- Minimize ambient noise.
- Place mic at **ear height**.
- Repeat measurements after treatment for validation.

## 7. Limitations

- Assumes **linear time-invariant systems**.
- Microphone and speaker imperfections affect accuracy.
- Ensure sufficient sweep level for good SNR without distortion.

## 8. Recommended Reference Book

**Master Handbook of Acoustics** by F. Alton Everest and Ken Pohlmann (Sixth Edition, McGraw-Hill).

Comprehensive coverage of room acoustics fundamentals, measurement techniques, and practical treatment strategies.

## 9. Conclusion

Using REW for acoustic measurements is a **cost-effective and reliable approach** for room analysis and treatment planning, enabling optimal acoustic environment design for clarity, intelligibility, and sound quality.

*Prepared by Dr. Janaka V. Wijayakulasooriya*